

L74 Track and Race Products 8 Ennerdale Drive Perton West Midlands WV6 7PF 07958 399 046

E-Mail: sales@L74trackandrace.co.uk Web: www.L74trackandrace.co.uk

## **ZX10 2016> Installation instructions**

- 1. Remove rear wheel, axel blocks and adjustment pins from swing arm
- 2. Disconnect traction sensor, rear brake line from master cylinder and remove rear calliper and calliper bracket
  - 3. Fit Lightech Chain adjusters using the fittings and instructions provided in the Lightech box, (Note the captive nut assembly fits to the exhaust side)
- 4. Fit the sprocket side wheel rest plate by drilling and tapping the swing arm, fix into place with the pins provided.
- 5. It is not essential but it does help to chamfer the brake pads to give a leading edge for the brake disc to slide into, this is easier to do at this stage by removing the pads from the caliper
- 6. Slide the calliper plate on to the captive nut attachment and fix into place using the grub screw (Note take care not to overtighten, this just needs to be pinched up)
  - 7. Connect the Brembo calliper using the 2 M8 button head pins provided
- 8. Connect new brake line and bleed all air out (note it helps to remove the calliper and turn it upside down to remove all air) **Do not overfill reservoir** 
  - 9. Insert rear wheel onto the resting plate and calliper plate
- 10. Lubricate and insert spindle but do not tighten up (Note this is a left hand thread Anti clockwise to tighten)
  - 11. Adjust the Lightech chain adjusters to tension the chain
    - 12. Tighten up rear spindle
- 13. Practise removing and inserting the wheel. (Note a 200 profile tyre has to come out at an angle)
  - 14. Laugh at your mates still struggling with their rear wheels

15. Ride safe

## **Please Note:**

These products are designed to be fitted with basic tools but some items will require drilling and tapping of the swing arm, plus the bleeding of your rear brake calliper.

Therefore, we recommend fitting to be done by trained professionals.